




INSTALLATION MANUAL PART 2/2

SAFERA Power Control Units PCU5-P and PCU4-U


INSTALLATION MANUAL

SAFERA Power Control Units PCU5-P and PCU4-U

Compatibility of Power Control Unit © Uncompatible installation may cause false alarms.				
Power Control Unit for cook-tops without oven. SAFERA PCU5-P	✓	✓	-	-
Power Control Unit for cookers with oven. SAFERA PCU4-U	✓	✓	✓	✓



- ▲ Make sure that there is no power supply to the cooker and the oven by removing their fuses. Also ensure that the cooker is switched off.
- ▲ OUT-wires are always energized when the power control unit is connected to the electrical network. If a wire is loose, it must be properly covered.

📖 Install the power control unit © so that it is not exposed to moisture. Check that all cables can move freely.




INSTALLATION: PCU5-P


Power Control Unit for cooktops without oven



Connect cooktop with 3-pin plug





Optional water sensor connection



8 Don't reconnect the power to the cooker yet, see installation manual Part 1/2 for next steps.

INSTALLATION: PCU4-U

Power Control Unit for cookers with oven



- 1 Remove the U-bridges between the cooker's L-inputs: see connection diagram on the right.
- 2 Couple the protective earth first (PE).
- 3 Couple the other wires.
- 4 Don't reconnect the power to the cooker yet, see installation manual Part 1/2 for next steps.